



Tree Spade

The loader mounted tree spade allows you to remove an 18" root-ball and transplant it. This unit is available in direct-mount or quick-attach style.

*Note-results may vary on ground conditions and loader capacity.

